

## Quick, simple 3 step service process

1

Open door, tear off liner and remove waste



2

Pull down new liner and tie a knot



3

Tuck liner into cavity and close door

